



# FLOOR INSTALLATION

BG Инструкция за монтаж в плаваща система

CZ Návod k montáži v systému plovoucím

D Verlegeanleitung zur schwimmenden Verlegung

DK Vejledning til montering i flydende system

ES Instrucciones de montaje en el sistema flotante

EST Paigaldamisjuhend ujjuvas süsteemi

FIN Asennusohje kelluvalle lattijärjestelmälle

FR Notice de pose pour le système flottant

GB Floating Floor Installation Guide

GR Οδηγίες συναρμολόγησης του συστήματος πλωτού

HR Instrukcija montaže za sistem plivajućih i ljepljenih podova

I Istruzione di montaggio con il metodo di pavimento galleggiante

LT Montavimo plaukiojančioje sistemoje instrukcija

LV Montāžas instrukcija ar peldošo metodi

NO Monteringsinstruksjon i flytende system

NL Instructie voor de montage bij zwevende vloer

PL Instrukcja montażu w systemie pływającym

RO Instrucțiuni de montaj în sistemul plutitor

RU Инструкция монтажа в плавающей системе

S Monteringsanvisningar för flytande system

SK Návod za montážo plavajočih podov

SLO Navodila za plavajoče polaganje

SR Uputstvo za plivajuću ugradnju


TR Yüzer sistem ile montajla ilişkin talimatname

UA Інструкція по монтажу плаваючим способом

ÉMISSIONS DANS L'AIR INTÉRIEUR



## PREINSTALLATION



## IDENTIFY LOCK




## BARCLICK

SNAP TYPE



BARCLICK



## BARLOCK


FOLD-DOWN TYPE



5Gs



5Gc



## CAUTION!

